



Description

Model SA1 smart sensor modules are designed to detect and monitor various gases in ambient air. The modules consist of a target specific gas detection sensor and a microprocessor-based signal conditioning circuit. Both are housed in a metallic enclosure fitted with gold plated connecting pins. The “Smart Sensor Module” is factory programmed for a specific gas and range of sensitivity. On power up the gas type, measurement range and previous zero and span calibration data points are read by the transmitter facilitating a fully automated startup. The modules can be used with any of Safeguard Analytics gas detection transmitters.

Model SA1-C2H4O ETO (Ethylene Oxide)

Specification*

Detector Type	Electrochemical
Detection Method	Diffusion
Range of Sensitivity**	0-20 PPM
Response Time	T90 ≤ 120s
Accuracy	± 2% FS
Zero Drift	< 2% per month
Span Drift	< 2% per month
Temperature Range	-40°C to +50°C; -40°F to 122°F
Humidity Range	15% to 90% RH non-condensing
Pressure Range	1 atm ±.1
Input Power	~ 3.5 to 5 VDC
Power Consumption	2.64 milliwatts
Detector Life Expectancy	>2 years
Detector Warranty	1 years

*Specifications subject to change without notice **Contact Safeguard Analytics for additional ranges

Cross Interference Data

Interfering Gas	Concentration	Response	Interfering Gas	Concentration	Response
CO	100	40	CH2O	5	10
C2H5OH	30	21	H2	100	1
HCOOH	40	40	NO2	5	0
CH3OH	80	55	TBM	10	11
H2S	20	40	NO	50	40
C6H6	100	10	C7H8	30	6
NH3	80	0	C8H10	25	5

Caution: Cross interference data is based on small lot sampling and does not claim to be complete. Referenced data may represent testing conducted by third party sensor suppliers as well as testing conducted by Safeguard Analytics. Interfering gases should not be used for calibration.